


REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.




MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD

HUMBUCKER COLOUR KEY	
1	NORTH Start wire —
2	NORTH Finish wire —
3	SOUTH Finish wire - - - -
4	SOUTH Start wire —

Notes:-
 Master Push/Pull Pot - pull out for single coils in all 6 positions.
 The DPDT switch shows two dotted wires - choose & solder only one!
 The Green wire will voice the North Coils (normally the slug coils).
 The Blue wire will voice the South Coils (normally the screw coils).
 Keep unscreened wires as short as possible.
 The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow key.



FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 024 : Last Updated Oct 2013


REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.




MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD

HUMBUCKER COLOUR KEY	
1	NORTH Start wire —
2	NORTH Finish wire —
3	SOUTH Finish wire - - - -
4	SOUTH Start wire —

Notes:-
 Master Push/Pull Pot - pull out for single coils in all 6 positions.
 The DPDT switch shows two dotted wires - choose & solder only one!
 The Green wire will voice the North Coils (normally the slug coils).
 The Blue wire will voice the South Coils (normally the screw coils).
 Keep unscreened wires as short as possible.
 The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow key.



FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 157 : Last Updated Feb 2016